

# External disk on USB prot ROS7

on a linux machine

- connect the USB stick/disk
- delete all partitions

```
parted -a optimal /dev/sd?  
rm 1
```

- format the disk ext4

```
mkfs.ext4 -m 0
```

on the Mikrotik router

- insert the usb stick/disk in the usb port.
- log in, start a terminal and display:

```
/disk/print  
Flags: B - BLOCK-DEVICE; M - MOUNTED  
Columns: SLOT, MOUNT-POINT, MODEL, SERIAL, INTERFACE  
#   SLOT  MOUN  MODEL                      SERIAL                      INTERFACE  
0 BM usb1  usb1  Kingston DataTraveler Max  204479A6A95081A50275  USB 3.20  
5000Mbps
```

From:  
<https://wiki.auriel.nl/> -

Permanent link:  
[https://wiki.auriel.nl/doku.php?id=installatie\\_handleidingen:mikrotik:usb-disk&rev=1758370560](https://wiki.auriel.nl/doku.php?id=installatie_handleidingen:mikrotik:usb-disk&rev=1758370560)



Last update: **2025/09/20 14:16**